



Valley Tent Rental, L.L.C.

WWW.VALLEYTENT.COM * (201)-476-5666

PROPANE GRILL

1. Prior to opening main cylinder valve, and lighting grill, place all control knobs in the "**CLOSED**" position (turned to the left).
2. Open main cylinder valve. Hold a lit butane gun next to a burner and turn the burner control knob to "**OPEN**" (pointing at you). The burner will ignite instantly. The second burner in each section will instantly light by simply turning it on. Since each section is ignited separately, only light the section required.
3. Once burners are lit, adjust the control knobs to desired temperature.
4. When finished cooking close all control knobs, close main cylinder valve and disconnect propane cylinder.